PYLE®

PMP50

Professional Piezo Dynamic Megaphone

USER MANUAL

www.PyleAudio.com

PMP50 - Professional Piezo Dynamic Megaphone



Megaphone for handheld or shoulder-slung use (straps supplied). Detachable anti-howl microphone with on-off switch and volume control. Metal and ABS construction.

Operating Instructions:

1. When carrying the microphone on the shoulder press the (1) press-to-talk power on-off switch on the left side of the microphone.
2. When holding the megaphone at the grip fix the microphone hanger inlet in the microphone fixing hander, then press the (2) press-to-talk power on-off switch back with your index finger.
3. Position the speaker opening mouth towards the object, and speak through the microphone mouthpiece. Bring the microphone mouthpiece close to your lips and speak normally.
4. Turn the sound volume control, on the right hand side of the microphone and adjust the sound level to the desired optimum level without causing howling.



Replacing Batteries:

1. Loosen the locking screw of the battery compartment cover on the back of the body. The battery compartment cover comes off.
2. Insert 8 x type C (UM-2) batteries in the battery case observing correct polarity
3. Insert the battery case with batteries into the battery compartment of the megaphone observing correct polarity.



Notes:

- Make sure the batteries are inserted correctly observing correct polarity.
- Remove the batteries when the megaphone is not in use for a long period of time.
- Drained batteries do not give sufficient sound volume. Replace the batteries at regular intervals.

Technical Specifications

Range	1200 Yards
Power	50 Watts
Weight	2.86 Lbs.
Dimensions	9” diameter x 13 ¾ length